

Modding the Nokia dBox

These cables go from the AV-Switch to the base of the corresponding transistors. Soldering these is somewhat tricky.

